

Omnia Service

Via Cesare Battisti, 12
31015 Conegliano (TV) - Italy
Fax: 0438-450202

**CATALOGO PARTI DI RICAMBIO
SPARE PARTS CATALOGUE****PIANO DI COTTURA ELETTRICO
ELECTRIC COOKER TOP**

PNC	Model	Ref.	Page
168 809	MC/E1	a	1
168 810	MC/E2	b	1
168 811	MCV/E2	c	2
168 812	MCV/E3	d	2
168 009	RC/E1	e	1
168 010	RC/E2	f	1
168 011	RCV/E2	g	2
168 012	RCV/E3	h	2

Indice

Pag. 1-2 Piano cottura e componenti
3 Lista ricambi

Index

Cooker top and components
Spare parts list


Marchio / Brand: Z - E - P
Paese / Country: Tutti / All

Da Ser. Nr. / From ser. nr.: 810.....

Ed. 9811

Doc. Nr.:


2 - 04 004



Piastre Speciali

Piastra	Art.	Ric.
1500 W - 400 V	6178.179.00	003930
2600 W - 400 V	6178.180.00	003931
1500 W - 440 V	6178.181.00	004014
2600 W - 440 V	6178.182.00	003929

PIANO DI COTTURA ELETTRICO
ELECTRIC COOKER TOP PR 700



Piastra Speciali

Piastra	Art.	Ric.
1500 W - 400 V	6178.179.00	003930
2600 W - 400 V	6178.180.00	003931
1500 W - 440 V	6178.181.00	004014
2600 W - 440 V	6178.182.00	003929

PIANO DI COTTURA ELETTRICO SU VANO
ELECTRIC COOKER ON CUPBOARD

PR 700