




**SA16AGB**

**Edition 20060711-**



Pos	Code	Description	Info
001	3AG0390	FRONT PANEL	15/12/2001-
002	37Q2050	DRAWER GASKET	15/12/2001-
003	35Q6090	COUNTER DOOR	15/12/2001-
004	32A2200	POWER SUPPLY CABLE	15/12/2001-
005	35Q6080	FAN GUARD	15/12/2001-
006	32M5960	TANGENTIAL FAN	15/12/2001-
007	34D5730	EVAPORATO	15/12/2001-
008	30W1710	DEFROSTED WATER CNT.	15/12/2001-
009	35S6261	GUIDE	15/12/2001-
010	32G1021	HEATING EL. 160W.220V	15/12/2001-
011	36G2810	BEARING	15/12/2001-
012	36M2730	HINGE ASS.Y	15/12/2001-
013	30G1000	DOOR	15/12/2001-
014	37Q2040	DOOR GASKET	15/12/2001-
015	35G2230	COUNTER DOOR	15/12/2001-
018	30T2451	PIVOTING CASTOR	15/12/2001-
020	35W2870	WELL	15/12/2001-
021	30M7270	TOP	15/12/2001-
022	32M2510	FAN	15/12/2001-
023	36A2430	"GRID ""525"""	15/12/2001-
024	35V3470	GUIDE SUPPORT	15/12/2001-
025	35U7030	GUIDE SUPPORT	15/12/2001-
026	36D9360	FOOT HOUSING ASS. Y	15/12/2001-
027	35A1860	REAR SIDE	15/12/2001-
028	33A0180	FILTER	15/12/2001-
030	33A1200	AUXIL.VALVE	15/12/2001-
032	35S3050	TRAY SLIDE	15/12/2001-
033	36Z0300	COND. TRAY	15/12/2001-
034	30T2051	HINGE BRACKET	15/12/2001-
035	36M2740	DOOR HINGE	15/12/2001-
038	3082160	CONTROL BOARD	11/07/2006-
039	3082240	THERMOREGULATOR	11/07/2006-
040	32W3970	BIPOLAR SWITCH	11/07/2006-
042	35A1850	PANEL	15/12/2001-
043	34D6160	MOTOR GROUP	15/12/2001-
044	32M6870	FAN MOTOR	15/12/2001-
045	32V3880	RELAY	15/12/2001-
046	32V3890	ENGINE CUTOUT	15/12/2001-
047	34D6150	COMPRESSOR	15/12/2001-
048	32Z2750	COIL	15/12/2001-
049	33A0510	DEFROST SOL. VALVE	15/12/2001-
050	32Z2700	CONDENSER	15/12/2001-
054	35C5270	EVAPORATOR GUARD	15/12/2001-
056	32V1500	CONDENSER	15/12/2001-
057	35U7040	GUIDE SUPPORT	15/12/2001-
058	3060620	SILK-SCREE.PANEL	11/07/2006-
059	3082180	PANEL BOARD	11/07/2006-
060	32D0740	TERMINAL BOARD	11/07/2006-