



135-4

Edition 20030709-

| Pos | Code | Description | Info |
|-----|---------|---------------------------|-------------|
| 002 | 3178300 | PLUG | 29/01/2001- |
| 003 | 36E2790 | CONDENS. DRAIN | 19/06/2001- |
| 004 | 40K4200 | BODY | 15/05/1997- |
| 005 | 30F1010 | FRIDGE DOOR | 15/12/2001- |
| 005 | 30F1010 | FRIDGE DOOR | 15/12/2001- |
| 006 | 30Q2400 | LAMP GUARD | 15/05/1997- |
| 007 | 3AT1150 | FOOT HOUSING | 15/05/1997- |
| 008 | 30T5920 | BOTTOM BRACKET | 15/05/1997- |
| 009 | 32A2200 | POWER SUPPLY CABLE | 15/05/1997- |
| 010 | 36Z0490 | ENGINE CUTOFF | 16/07/1999- |
| 011 | 32D0020 | CABLE CLAMP Ø 4 - 12 | 16/07/1999- |
| 012 | 32D0710 | THREE-POLE CONNECTOR | 15/05/1997- |
| 013 | 32D0740 | TERMINAL BOARD | 16/07/1999- |
| 014 | 32G1810 | HEATING ELEMENT | 15/05/1997- |
| 015 | 32M1080 | FAN | 15/05/1997- |
| 017 | 32M6870 | FAN MOTOR | 05/12/2001- |
| 018 | 32M4041 | MOTOR | 15/05/1997- |
| 019 | 32W1320 | MICROSWITCH | 15/05/1997- |
| 020 | 32W2331 | BIPOLAR SWITCH | 15/05/1997- |
| 021 | 32W2350 | LAMP | 15/05/1997- |
| 022 | 32W2360 | LAMP-HOLDER | 15/05/1997- |
| 023 | 32W3190 | PILOT-LIGHT 1-POLE SWITCH | 15/05/1997- |
| 024 | 32X0120 | GROMMET Ø 21 | 15/05/1997- |
| 025 | 32X0340 | GROMMET | 15/05/1997- |
| 026 | 32V1420 | CONDENSER | 16/04/1999- |
| 027 | 32Z2750 | COIL | 15/05/1997- |
| 029 | 32V2520 | DIGITAL THERMOREGULATOR | 16/07/1999- |
| 031 | 32V1290 | RELAY | 16/04/1999- |
| 032 | 32V1450 | ENGINE CUTO | 16/04/1999- |
| 033 | 33A1200 | AUXIL.VALVE | 15/05/1997- |
| 034 | 33A0180 | FILTER | 15/05/1997- |
| 035 | 34D7300 | CONDENSER | 16/04/1999- |
| 036 | 34D6760 | COMPRESSOR | 16/04/1999- |
| 037 | 34D2610 | EVAPORATOR | 15/05/1997- |
| 038 | 34D7290 | MOTOR UNIT | 16/04/1999- |
| 039 | 35B9510 | CENTRAL EVAP. GUARD | 15/05/1997- |
| 040 | 35P0950 | RIGHT EVAP. GUARD | 15/06/1998- |
| 041 | 35P0960 | LEFT EVAP. GUARD | 15/06/1998- |
| 042 | 36E0980 | PANEL-BOARD COVER | 16/07/1999- |
| 043 | 35G6520 | COVER | 15/05/1997- |
| 044 | 35G6560 | MOTOR ROOM HEAD | 15/05/1997- |
| 045 | 35R1560 | SUPPORT | 16/07/1999- |
| 046 | 35Q7350 | MICROSWITCH GUARD | 15/05/1997- |
| 047 | 35S3050 | TRAY SLIDE | 15/05/1997- |
| 048 | 35V0360 | GUARD SUPPORT | 15/05/1997- |
| 049 | 35V0880 | STIFFENING | 15/05/1997- |
| 050 | 35V0890 | LOCK SUPPORT | 15/05/1997- |
| 051 | 35V1010 | CONTROL BOARD C | 16/07/1999- |
| 053 | 35V1710 | TRAY TRIM | 15/05/1997- |
| 054 | 35V2270 | STIFFENING | 15/05/1997- |
| 055 | 35V2940 | FAN SUPPORT | 15/05/1997- |

| Pos | Code | Description | Info |
|-----|---------|--------------------------------|-------------|
| 056 | 35W4350 | TRAY ASS.Y | 15/05/1997- |
| 057 | 36A0710 | GRID | 06/12/1997- |
| 058 | 36A3660 | UNION GRID | 15/05/1997- |
| 059 | 36D1250 | TRIM FRAME | 15/05/1997- |
| 060 | 36D1270 | TRIM FRAME | 15/05/1997- |
| 061 | 36D1290 | TRIM FRAME | 15/05/1997- |
| 062 | 36C3940 | ST-STEEL FO | 22/07/1999- |
| 063 | 36D9470 | RACK | 15/05/1997- |
| 064 | 36D9480 | LOCK BRACKET | 15/05/1997- |
| 065 | 36D9490 | TOP BRACKET | 15/05/1997- |
| 066 | 36D9921 | SPACER | 15/05/1997- |
| 067 | 36D9980 | TOP HANDLE GUARD | 15/05/1997- |
| 068 | 36D9990 | BOTTOM HANDLE GUARD | 15/05/1997- |
| 069 | 36G6520 | HINGE | 15/05/1997- |
| 070 | 36M0140 | KEY LOCK | 15/05/1997- |
| 072 | 36Z0300 | COND. TRAY | 15/05/1997- |
| 073 | 36Z6401 | CONTROL BOARD | 09/07/2003- |
| 074 | 36Z6410 | COMPONENT GUARD | 16/07/1999- |
| 075 | 36Z6441 | PLASTIC-COATED TRAY 860X432X85 | 15/05/1997- |
| 076 | 37M4740 | LAMP PANEL | 15/05/1997- |
| 077 | 37Q2600 | DOOR GASKET | 15/05/1997- |
| 078 | 37Q7370 | LAMP GASKET | 15/05/1997- |
| 079 | 3AA3520 | CONTROL BOARD | 16/07/1999- |
| 080 | 36D7100 | CONDENS. DRAIN | 15/05/1997- |
| 081 | 35X1640 | DRAIN TRAP | 11/05/1998- |
| 082 | 36Q1400 | PLUG | 15/05/1997- |
| 083 | 33A0510 | DEFROST SOL. VALVE | 15/05/1997- |
| 084 | 6011970 | DOOR UNIT | 15/12/2001- |
| 085 | 35V2120 | RESISTOR FASTENER | 15/05/1997- |
| 086 | 35V2140 | RESISTOR FASTENER | 15/05/1997- |
| 087 | 30T5950 | CENTRAL RISER | 15/05/1997- |
| 088 | 3600770 | SPACER | 15/05/1997- |
| 089 | 3AT1340 | BACK RISER | 14/07/1998- |
| 090 | 36G5251 | RACK SUPPORT | 15/05/1997- |
| 092 | 6011960 | DOOR UNIT | 15/12/2001- |
| 093 | 36C2020 | FAN GUARD | 15/05/1997- |
| 094 | 35X1550 | DRAIN PIPE | 11/05/1998- |
| 095 | 36M0080 | LOCK U BOLT | 15/05/1997- |
| 096 | 36M0090 | LOCK BRACKET | 15/05/1997- |
| 097 | 36M1380 | LOCKING HOOK | 15/05/1997- |
| 098 | 30T5900 | INTERMED. BRACKET | 15/05/1997- |
| 100 | 32Z3470 | TRANSFORMER | 16/07/1999- |
| 101 | 30T5910 | RH BOTTOM BRACKET | 15/05/1997- |
| 102 | 36D1260 | TRIM FRAME | 15/05/1997- |
| 103 | 35X0920 | DRAIN PIPE | 15/05/1997- |
| 104 | 3170250 | PLUG | 29/01/2001- |
| 105 | 35E2550 | SUPPORT | 19/06/2001- |