



**135BN**

**Edition 20030709-**



Pos	Code	Description	Info
002	3178300	PLUG	01/01/1996-
003	36E2790	CONDENS. DRAIN	19/06/2001-
004	6011950	DOOR UNIT	15/12/2001-
005	3AA2310	EVAPORATOR G	08/11/1996-
006	40K7130	BODY	01/01/1996-
007	30F1000	FRIDGE DOOR	15/12/2001-
008	3AA2390	EVAP.GUARD	08/11/1996-
009	3AT1150	FOOT HOUSING	10/03/1997-
010	30T5810	BOTTOM BRACKET	01/01/1996-
012	32A2200	POWER SUPPLY CABLE	05/08/1997-
013	36Z0490	ENGINE CUTOUT	30/06/1999-
014	32D0020	CABLE CLAMP Ø 4 - 12	30/06/1999-
015	32D0710	THREE-POLE CONNECTOR	01/01/1996-
016	32D0740	TERMINAL BOARD	30/06/1999-
017	32G1800	HEATING ELEMENT	01/01/1996-
018	32G1820	HEATING ELEMENT	01/01/1996-
019	32G1840	HEATING ELEMENT	01/01/1996-
020	32M1080	FAN	01/01/1996-
021	32M1550	FAN	01/01/1996-
022	32M2510	FAN	01/01/1996-
023	32M3280	FAN	01/01/1996-
024	32M4041	MOTOR	03/11/1999-
024	32M6870	FAN MOTOR	05/12/2001-
025	32M4041	MOTOR	20/11/1996-
026	32W0271	LIGHT	01/01/1996-
027	32W1320	MICROSWITCH	01/01/1996-
028	32W2331	BIPOLAR SWITCH	01/01/1996-
029	32W2350	LAMP	01/01/1996-
030	32W2360	LAMP-HOLDER	01/01/1996-
031	32W3190	PILOT-LIGHT 1-POLE	01/01/1996-
032	32X0120	SWITCH GROMMETØ 21	01/01/1996-
033	32X0340	GROMMET	01/01/1996-
034	32Z9430	CONDENSER	15/04/1996-
035	32Z1090	THERMOSTAT	30/06/1999-
036	32Z2750	COIL	01/01/1996-
038	34D6180	CONDEN.+BAFFLE	26/11/1998-
039	32V1820	ENGINE CUTOUT	26/11/1998-
040	32V1810	RELAY	26/11/1998-
041	32V2520	DIGITAL THERMOREGULATOR	30/06/1999-
045	32Z9410	RELAY	15/04/1996-
046	32Z6710	ENGINE CUTOUT	01/01/1996-
047	33A0510	DEFROST SOL. VALVE	01/01/1996-
048	33A0180	FILTER	01/01/1996-
049	33A1200	AUXIL.VALVE	01/01/1996-
050	34D7160	COMPRESSOR	26/11/1998-
051	34D4801	CONDENSER	18/12/1996-
052	34D2600	EVAPORATOR	01/01/1996-
053	34D2630	EVAPORATOR	01/01/1996-
054	34D7280	MOTOR UNIT	26/11/1998-
055	34D4590	MOTOR ASS.Y	01/01/1996-
056	34D5360	COMPRESSOR	15/04/1996-

Pos	Code	Description	Info
057	36E0980	PANEL-BOARD COVER	30/06/1999-
058	35G6520	COVER	01/01/1996-
059	35G6560	MOTOR ROOM HEAD	01/01/1996-
060	35R6810	PANEL BOARD	30/06/1999-
061	35Q7350	MICROSWITCH GUARD	01/01/1996-
062	35S3050	TRAY SLIDE	01/01/1996-
063	32V2880	RELAY	01/01/1996-
064	35V0360	GUARD SUPPORT	01/01/1996-
065	35V0370	FRONT GUARD	01/01/1996-
066	35V0880	SUPPORT STIFFENING	01/01/1996-
067	35V0890	LOCK SUPPORT	01/01/1996-
068	35V1010	CONTROL BOARD C	30/06/1999-
069	35V1150	FAN SUPPORT	01/01/1996-
070	35V1450	HEATING ELEMENT SUPPORT	01/01/1996-
071	35V1710	TRAY TRIM	01/01/1996-
072	35V2130	RESISTOR FASTENER	01/01/1996-
073	35V2270	STIFFENING	01/01/1996-
074	35W4350	TRAY ASS.Y	01/01/1996-
075	35W4360	TRAY ASS.Y	01/01/1996-
076	35X1640	DRAIN TRAP	01/01/1996-
077	35X1740	DRAIN PIPE	01/01/1996-
078	36A0710	GRID	06/12/1997-
079	36D3940	FRAME BORDER	01/01/1996-
080	36D1270	TRIM FRAME	01/01/1996-
081	36D1290	TRIM FRAME	01/01/1996-
082	36D7100	CONDENS. DRAIN	01/01/1996-
083	36C3940	ST-STEEL FO	22/07/1999-
084	36D9470	RACK	01/01/1996-
085	36D9480	LOCK BRACKET	01/01/1996-
086	36D9490	TOP BRACKET	01/01/1996-
087	36D9980	TOP HANDLE GUARD	01/01/1996-
088	36D9990	BOTTOM HANDLE	01/01/1996-
089	36G6520	GUARD HINGE	01/01/1996-
090	36M0140	KEY LOCK	01/01/1996-
092	36Q1400	PLUG	01/01/1996-
093	36Z0300	COND. TRAY	01/01/1996-
094	36Z6401	CONTROL BOARD	09/07/2003-
095	36Z6410	COMPONENT GUARD	30/06/1999-
096	36Z6431	"TRAY ""TN"" 460X385X85"	01/01/1996-
097	36Z6471	"PLASTIC-COATED TRAY ""BT"" 460X3"	01/01/1996-
098	37M4740	LAMP PANEL	01/01/1996-
099	37Q2590	DOOR GASKET	01/01/1996-
100	37Q7370	LAMP GASKET	01/01/1996-
101	3AA3580	CONTROLBOARD	30/06/1999-
102	32M6860	FAN MOTOR	10/12/2001-
103	30A2130	INTERMEDIATE PANEL	01/01/1996-
104	3600770	SPACER	01/01/1996-
107	36C2020	FAN GUARD	01/01/1996-
108	36C2031	FAN GUARD	10/01/1997-
109	32V1830	CONDENSER	26/11/1998-
110	32V2980	DIGITAL THERMOREGULATOR	30/06/1999-

<b>Pos</b>	<b>Code</b>	<b>Description</b>	<b>Info</b>
111	35R1560	SUPPORT	30/06/1999-
112	32Z3470	TRANSFORMER	30/06/1999-
113	32V3720	RELAY	20/07/2000-
114	35T4840	TIMER SUPPORT	30/06/1999-
115	32Z9420	ENGINE CUTOFF	15/04/1996-
116	35E2550	SUPPORT	19/06/2001-