




OM0FR1E

Edition 20001201-



Pos	Code	Description	Info
001	0M0FR1E-Pos.001	BOTTOM	01/12/2000-
002	0M0FR1E-Pos.002	LATERAL SIDES	01/12/2000-
003	0M0FR1E-Pos.003	BOTTOM REINFORCEMENT	01/12/2000-
004	0M0FR1E-Pos.004	SWITCHES SUPPORT	01/12/2000-
005	0M0FR1E-Pos.005	FRONTAL PANEL	01/12/2000-
006	0M0FR1E-Pos.006	REAR EXTERNAL CHIMNEY	01/12/2000-
007	0M0FR1E-Pos.007	TOP WITH TANK	01/12/2000-
008	36A4670	FILTER	01/12/2000-
009	0M0FR1E-Pos.009	HEATING ELEMENT HOLDER FRONT	01/12/2000-
009	0M0FR1E-Pos.009	HEATING ELEMENT HOLDER	01/12/2000-
010	36A4690	BASKET	01/12/2000-
011	0M0FR1E-Pos.011	COVER	01/12/2000-
012	32V4540	IMIT THERMOSTAT	01/12/2000-
013	32W3830	EGO SWITCH	01/12/2000-
014	33D2840	TAP	01/12/2000-
015	32V4630	SAFETY THERMOSTAT	01/12/2000-
016	36C4380	FOOT - DIAM.30 / 8MA	01/12/2000-
017	36M6920	THERMOSTAT'S KNOB	01/12/2000-
018	36M6910	SWITCH 'S KNOB	01/12/2000-
019	32W3710	WHITE WARNING LAMP COVER	01/12/2000-
020	32W3720	GREEN WARNING LAMP COVER	01/12/2000-
021	32W3730	WARNING LAMP	01/12/2000-
022	32V4730	CONTACTOR	01/12/2000-
023	32W3700	MICROSWITCH	01/12/2000-
024	32D1680	5 POLES TERMINAL BOARD	01/12/2000-
025	0M0FR1E-Pos.025	WATER WASTE PIPE - DIAM. 22	01/12/2000-
026	0M0FR1E-Pos.026	HEATING ELEMENT KEEPER	01/12/2000-
027	36M6850	COVER HANDLE	01/12/2000-
028	32G2940	HEATING ELEMENT 1800W	01/12/2000-
029	0M0FR1E-Pos.029	SCREW	01/12/2000-
030	0M0FR1E-Pos.030	BASKET HOLDER BAR	01/12/2000-
031	0M0FR1E-Pos.031	HEATING ELEMENT LEVER	01/12/2000-
032	0M0FR1E-Pos.032	BULB CLIP	01/12/2000-