

Rif./Ref.	Codice/Code	Sigla /Features	Descrizione/Description
1	SL2528		Shaft
2	SL2917		Tap
3	SL2526		Calotte
4	SL2591	ø25xø47x8	Oil seal
5	SL3125	6204 2RS	Bearing
6	SL0082	ø47	Seeger
7	SL2593	ø20xø47x8	Oil seal
8	SL0130		Gear
9	SA2200	Assembly	Calotte
+ 10	SL2924		Knob
11	SL0125		Gear
12	SL2589		Shaft
13	SA1016	400V/3Ph/50Hz	Stator
13	SA1017	230V/1Ph/50Hz	Stator
14	SL0128		Gear
15	SL0127	ø17xø40x8	Oil seal
16	SL0131	6203 2RS	Bearing
17	SL2600	400V/3Ph/50Hz	Rotor
17	SL2601	230V/1Ph/50Hz	Rotor
18	SL1841	3Ph+Gnd	Electric cable
18	SL1671	1Ph+N+Gnd	Electric cable
19	SL0186		Calotte
20	SL2833		Cover
21	SL1668	PG11	Cable clamp
+ 22	SL0134		Pusher
23	SL0136		Hopper
24	SL2566		Base
25	SL3986	Stainless-steel	Sleeve
25	SL2523R0	Food stuff treated cast-iron (without CE norms)	Sleeve
25	SL3987	Unger	Sleeve
+ 26	SA5500	Stainless-steel	Screw shaft
26	SA5400	Food stuff treated cast-iron (without CE norms)	Screw shaft

+ : ricambio consigliato / spare part suggested

Rif./Ref.	Codice/Code	Sigla /Features	Descrizione/Description
26	SA5700	Unger	Screw shaft
27	SL0823		Pivot
27	SL0824	Unger	Pivot
+ 28	//////////		Cutter
+ 29	//////////		Plate
30	SL0197	Stainless-steel	Handwheel
30	SL3328R0	Aluminium (without CE norms)	Handwheel
31	SL0180		Container
+ 32	SL0891	Start-stop	Push button
+ 33	SL0883		Electronic card
34	SL0931	20µF	Condenser
35	SL0176		Bracket
36	SL2651		Bottom
37	SL0235		Foot
38	SL0054		Switch

