


MCD320-420-520-420S-520S



MCD320-420-520-420S-520S

Pos. Ref.	Codice Code	Caratteristiche Features	Descrizione Description	
1	CO5207	(MCD320)	Coperchio	Cover
1	CO5208	(MCD420-420S)	Coperchio	Cover
1	CO5209	(MCD520-520S)	Coperchio	Cover
2	CO5210	(MCD320)	Guarnizione	Gasket
2	CO5211	(MCD420-420S)	Guarnizione	Gasket
2	CO5212	(MCD520-520S)	Guarnizione	Gasket
4	CO5213	(MCD320)	Gomma	Rubber
4	CO5214	(MCD420-420S)	Gomma	Rubber
4	CO5215	(MCD520-520S)	Gomma	Rubber
5	CO5216		Molla	Spring
6	SL4017	ø6 - Stainless steel	Seeger	Seeger
7	CO5217		Perno	Pivot
8	SL4018	ø8 - Stainless steel	Seeger	Seeger
9	CO5218		Perno	Pivot
10	CO5219		Snodo	Junction
11	CO5220		Cerniera	Hinge
12	CO5221		Boccola	Bush
13	CO5222	● Assembly (MCD320)	Barra saldante	Seal bar
13	CO5223	● Assembly (MCD420-420S)	Barra saldante	Seal bar
13	CO5224	● Assembly (MCD520-520S)	Barra saldante	Seal bar
14	CO5225	(MCD320)	Protezione	Protection
14	CO5226	(MCD420-420S)	Protezione	Protection
14	CO5227	(MCD520-520S)	Protezione	Protection
15	CO5228	● (MCD320)	Resistenza	Resistance
15	CO5229	● (MCD420-420S)	Resistenza	Resistance
15	CO5230	● (MCD520-520S)	Resistenza	Resistance
19	CO5231		Ghiera	Locking ring
20	CO5232	●	Microinterruttore	Microswitch
22	CO5233		O-ring	O-ring
23	CO5234		Flangia	Flange
24	CO5235		O-ring	O-ring
25	CO5236		Pistone	Piston
26	CO5237	●	Elettrovalvola	Electro-valve
27	CO5238	● (MCD320)	Elettropompa	Electro-pump
27	CO5239	● (MCD420-420S)	Elettropompa	Electro-pump
27	CO5240	● (MCD520-520S)	Elettropompa	Electro-pump
28	CO5241	●	Elettrovalvola	Electro-valve
29	CO5242	(MCD320)	Anello	Ring
29	CO5243	(MCD420-420S)	Anello	Ring
29	CO5244	(MCD520-520S)	Anello	Ring
30	CO5245	●	Elettrovalvola	Electro-valve
32	CO5246	● (MCD320)	Trasformatore	Transformer
32	CO5247	● (MCD420-420S)	Trasformatore	Transformer
32	CO5248	● (MCD520-520S)	Trasformatore	Transformer
34	CO5249		Piedino	Foot
36	CO5250	● (MCD320-420-520)	Scheda elettronica	Electronic card
36	CO5251	● (MCD420S-520S)	Scheda elettronica	Electronic card
37	CO5252		Vacuometro	Vacuum gauge
39	CO5253		Interruttore	Switch
40	SL3992	(MCD320-420-520)	Etichetta	Label
40	SL3993	(MCD420S-520S)	Etichetta	Label
41	CO5254	(MCD420S-520S)	Stampante	Printer
48	CO5255	● (MCD420S-520S)	Alimentatore	Power supply
49	CO5256	(MCD420S-520S)	Tastiera	Keyboard

(*) : fuori produzione / out of production

● : ricambio consigliato / spare part suggested