

Rif./Ref.	Codice/Code	Sigla /Features	Descrizione/Description
+ 1	SL0841		Pusher
2	SA1010		Hopper
3	SL3011		Magnet
4	SL3458		Flange
5	SL2587	ø35xø52x11	Oil seal
6	SL2548		Tap
+ 7	SL2924		Knob
8	SL3106	Stainless-steel	Sleeve
8	SL3268	Unger	Sleeve
+ 9	SA2300	Stainless-steel	Screw shaft
9	SA2400	Unger	Screw shaft
10	SL2520		Pivot
10	SL2560	Unger	Pivot
+ 11	////////		Cutter
+ 12	////////		Plate
13	SL2420	Stainless-steel	Handwheel
14	SL3473		Housing
+ 15	32W3240		Microswitch
16	SL3247		Support
17	SL3246		Bracket
18	SL3183	230V/1Ph/50-60Hz	Fan
19	SL3257		Net
20	SL3233		Covering
21	SL1668	PG11	Cable clamp
22	SL1841	3Ph+Gnd	Electric cable
22	SL1671	1Ph+N+Gnd	Electric cable
23	SL3577		Label
24	SA1083	Start-reverse	Push button
25	SL0807	Stop	Push button
26	MP0257	M22x1,5	Nut
27	SL3459		Bracket
28	SL3477		Gear box

+ : ricambio consigliato / spare part suggested

Rif./Ref.	Codice/Code	Sigla /Features	Descrizione/Description
29	SL3457		Flange
30	SL2588	51207	Bearing
31	SL3463		Shaft
32	SA1003	400V/3Ph/50Hz	Motor
32	SL2894	230V/1Ph/50Hz	Motor
33	SL3088	55µF	Condenser
+ 34	SL0999		Electronic card
35	SL3020		Spacer
36	SL3460	Three-phase	Bottom
36	SL3461R0	Single-phase	Bottom
37	SL1610	Three-phase	Foot
37	SL0235	Single-phase	Foot
38	SL0247		Reversing gear

