

Rif./Ref.	Codice/Code	Sigla /Features	Descrizione/Description
1	SL2833		Cover
2	SL0186		Calotte
3	SL0131	6203 2RS	Bearing
4	SA1014	400V/3Ph/50Hz	Stator
4	SA1015	230V/1Ph/50Hz	Stator
5	SA7500	400V/3Ph/50Hz	Rotor
5	SA7600	230V/1Ph/50Hz	Rotor
6	SL0121	ø5x10	Pin
7	SL0119	ø52	Seeger
8	SL0118	6205 2RS	Bearing
9	SL0117		Calotte
10	SA2800		Roller
+ 11	SL0106		Grip
12	SA1113		Lever press
13	SL3140		Washer
14	SL3138		Covering
+ 15	SL0885		Microswitch
16	SL0258		Stud
17	SL0108		Nut
18	SL2573		Tap
19	SA1012	Assembly	Casing
20	SL0174		Container
21	SL1841	3Ph+Gnd	Electric cable
21	SL1671	1Ph+N+Gnd	Electric cable
22	SL1668	PG11	Cable clamp
23	SL2988		Base
+ 24	SL0891	Start-stop	Push button
+ 25	SL3436	400V/3Ph/50Hz	Electronic card
+ 25	SL0556	230V/1Ph/50Hz	Electronic card
26	SL0177	16µF	Condenser
27	SL0176		Bracket
28	SL2651		Bottom

+ : ricambio consigliato / spare part suggested

Rif./Ref.	Codice/Code	Sigla /Features	Descrizione/Description	
29	SL0235		Foot	
30	SL0054		Switch	
31	SA1119	Assembly - 15/05/05 f.p.(*)	Casing	

